



User Manual

User Manual V1.2 2017

9TR01-00100

- Measures kWh, kVarh, kW, kVar, kVA, PF, Hz, dmd, V, A, etc.
- Bi-directional measurement IMP & EXP
- Two pulse outputs
- RS485 Modbus RTU / Mbus
- Din rail mounting 18mm
- 45A direct connect / 5A or 100mV CT Connect
- Better than Class 1 accuracy

1. Introduction

This document provides operating, maintenance and installation instructions of **9TR01-00100**

2. Specifications

2.1 General Specifications

Voltage AC (Un)	230V
Voltage Range	176~276V AC
Current Input	0.25~5(45)A (SDM120 45A) 0.25~5(6)A (SDM120 CT)
Power consumption	<2W/10VA
Frequency	50/60Hz (50Hz only for MID version)
AC voltage withstand	4KV for 1 minute
Impulse voltage withstand	6KV-1.2uS waveform
Overcurrent withstand	30Imax for 0.01s (SDM120 45A) 20Imax for 0.01s (SDM120CT)
Pulse output rate	1000imp/kWh (default) 1000/100/10/1 imp/kWh/kVarh (configurable)

Display	LCD with white backlit
Max. Reading	99999.9kWh (SDM120 45A) 999999 kWh (SDM120 CT)
2.2 Accuracy	
Voltage	0.5% of range maximum
Current	0.5% of nominal
Frequency	0.2% of mid-frequency
Power factor	1% of Unity
Active power	1% of range maximum
Reactive power	1% of range maximum
Apparent power	1% of range maximum
Active energy	Class 1 IEC62053-21 Class B EN50470-3 (MID product only)
Reactive energy	1% of range maximum

2.3 Environment

Operating temperature	-25°C to +55°C
Storage and transportation temperature	-40°C to +70°C
Reference temperature	23°C ±2°C
Relative humidity	0 to 95%, non-condensing
Altitude up to 2000m	
Warm up time	3s
Mechanical environment	M1
Electromagnetic environment	E2
Degree of pollution	2

2.4 Mechanics

Din rail dimensions	18x119x62 (WxHxD) DIN 43880
Mounting	DIN rail 35mm
Sealing	IP51 (indoor)
Material	self-extinguishing UL94V-0

3 Display

Initialization Display

When it is powered on, the meter will initialize and do self-checking.


1	88888888 $\frac{kWh}{H/M/A}$	Full screen It will last for 3 seconds.
2	020 105	Software version It will last for 3 seconds.
3	ct 100 $\frac{A}{\sim}$	CT1 (9TR01-00100 only) Primary current 1A-9999A Default: 5
4	000478 $\frac{kWh}{H/M/A}$	Total active energy(kWh)

After the self-checking program, the meter screen will display the total active energy (kWh)

*** Note: For the MID version of 9TR01-00100, the CT ratio can be set only once. Before you set the CT ratio, please check the ratio of the CT connected to the meter. For example, if the CT is 100/5A, please set CT1 to be 100.**

Scroll Display by button

There is a button on the front of the meter. After initialization and self-checking program, the meter display the measured values. The default page is total kWh. If the user wants to check other information, he needs to press the scroll button on the front panel.

	Click the button, the LCD display will scroll the measurements.
	Keep pressing the button for 3 seconds, the meter will enter set-up mode.

1	000478 $\frac{kWh}{H/M/A}$	Total active energy(kWh) Display format:0000.00~9999.99 ~10000.0~99999.9~0000.00
1-1	000245 $\frac{kWh}{H/M/A}$	Import active energy(kWh) Display format:0000.00~9999.99 ~10000.0~99999.9~0000.00
1-2	000232 $\frac{kWh}{H/M/A}$	Export active energy(kWh) Display format:0000.00~9999.99 ~10000.0~99999.9~0000.00
2	2 198 \angle	Voltage (V)
3	20.18 \triangleright	Current (A)
4	22 102 W	Active power (W)
5	F 5000	Frequency (F)
6	PF 100	Power factor (PF)
7	Address 1	Modbus Address or Primary address Default: 001
8	b 2400	Baudrate Default : 2400bps
9	None	Parity None/Even/Odd are optional Default: none
10	ct 100 $\frac{A}{\sim}$	CT 1 (9TR01-00100 only) Primary current 1A-9999A Default: 5 * Note: For the MID version, the CT ratio can be set only once.
11	ct 5 $\frac{A}{\sim}$	CT 2 (9TR01-00100 only) Secondary current 1A or 5A, Default: 5
12	H 0000	M-Bus secondary address High (M-Bus version only)
13	L 0000	M-Bus secondary address Low (M-Bus version only)
14	020 105	Software version In kind prevail


The display of each model:

9TR01-00100: Total kWh → Import kWh → Export kWh → Voltage
→ Current → Active power → Frequency → Power factor →
Address → Baudrate → Parity → CT 1 → CT 2 →

4. Communication

4.1 Pulse Output

The meter is equipped with 2 pulse outputs, which are fully isolated from the inside circuit. That generates pulses in proportion to the measured energy. The pulse outputs are polarity dependent, passive transistor output requiring an external voltage source for correct operation. For this external voltage source, the voltage shall be 5-27V DC, and the maximum input current shall be 27mA DC.



ATTENTION: Pulse output must be fed as shown in the wiring diagram below. Scrupulously respect polarities and the connection mode. Opto-coupler with potential-free SPST-NO Contact.

Contact range: 5~27VDC Max. current
Input: 27mA DC

4.2 RS485 output for Modbus RTU

The meter provides a RS485 port for remote communication. Modbus RTU is the protocol applied. For Modbus RTU, the following RS485 communication parameters can be configured from the Set-up menu.


Baud rate: 1200, 2400, 4800, 9600

Parity: NONE/EVEN/ODD


Stop bits: 1 or 2

Modbus Address: 1 to 247


5. Dimensions



6.2 Installation



6.3 Wiring diagram



6. Installation

6.1 Safety instruction

Information for your own safety

This manual does not contain all of the safety measures for operation of the equipment (module, device), because special operating conditions, and local code requirements or regulations may necessitate further measures. However, it does contain information which must be read for your personal safety and to avoid material damages. This information is highlighted by a warning triangle and is represented as follows, depending on the degree of potential danger.



Warning

This means that failure to observe the instruction can result in death, serious injury or considerable material damage.



Caution

This means hazard of electric shock and failure to take the necessary safety precautions will result in death, serious injury or considerable material damage.

Qualified personnel

Operation of the equipment (module, device) described in this manual may only be performed by qualified personnel. Qualified personnel in this manual means person who are authorized to commission, start up, ground and label devices, systems and circuits according to safety and Regulatory standards.

Proper handling

The equipment (device, module) may only be used for the application specified in the catalogue and the user manual, and only be connected with devices and components recommended and approved by Sirea.

- ◆ Use only insulating tools.
- ◆ Do not connect while circuit is live (hot).
- ◆ Place the meter only in dry surroundings.
- ◆ Do not mount the meter in an explosive area or expose the meter to dust, mildew and insects.
- ◆ Make sure the used wires are suitable for the maximum current of this meter.
- ◆ Make sure the AC wires are connected correctly before activating the current/voltage to the meter.
- ◆ Do not connect the meter to a 3 phase - 400VAC - network.
- ◆ Do not touch the meter connecting clamps directly with your bare hands, with metal, blank wire or other material as you may get an electrical shock.
- ◆ Make sure the protection cover is placed after installation.
- ◆ Installation, maintenance and reparation should only be done by qualified personnel.
- ◆ Never break the seals and open the front cover as this might influence the functionality of the meter, and will avoid any warranty.
- ◆ Do not drop, or allow physical impact to the meter as there are high precision components inside that may break.

7. Declaration of Conformity (for the MID approved version meter only)

Sirea declares that the single phase multifunction electrical energy meter correspond to the production model described in the EU-type examination certificate and the requirements of the Directive 2014/32/EU. Type examination certificate number 0120/SGS0141. Identification number of the Notified Body: 0120.